

OPERATOR INSTRUCTIONS

SACP48A-HS

STEP 1: Confirm that circuit breaker (6CB) is switched ON and CONTROL POWER pushbutton light (1PL) is lit.

- If not, check phase monitor relay (PMR) and emergency stop (ES) button.
- If INCORRECT POWER pushbutton light (2PL) is lit, check PMR for phase rotation and voltage setting.

STEP 2: Turn ON AIR FLOW switch (1SW)

STEP 3: Turn BLOWER switch (2SW) to require blower operating mode.

- VFD RUNNING pushbutton light (3PL) lit if blower is started using VFD.
- BYPASS RUNNING pushbutton light (5PL) lit if blower is started using bypass starter.
- Check blower circuit breaker overload (4OL) or VFD status if BLOWER TRIP pushbutton light (4PL) is lit.

STEP 4: Set blower running speed using SPD ADJ POT (potentiometer)

STEP 5: Cooling probe selection switch (4SW)

- Turn 4SW to RA - Cooling is based on return air control.
- Turn 4SW to SA - Cooling is based on supply air control.

STEP 6: Turn ON COOLING switch (5SW)

STEP 7: Turn OFF/LOCAL/HAND/REMOTE switch (3SW) to require compressor operating mode.

- OFF - Compressor is switched off.
- LOCAL - Compressor is operating with local controller.
- HAND - Compressor is operating in manual mode without the controller (manual on).
- REMOTE - Compressor is operating in remote mode without the controller (on/off by remote thermostat)

It is the customer's responsibility to always follow the written operating instructions of the unit and maintain safe work practices.